


# 安装说明 21334-03



订货号	L	S	A	A1	A2	A3	A4	A5	A6	A7	B	H	负载能力 每对 kg
21334-03-0200	200	205,5	26	-	-	128	160	14	-	-	19	27,1	22
21334-03-0250	250	255	26	-	-	160	192	32	-	-	19	27,1	25
21334-03-0300	300	304	26	-	-	224	256	18	-	-	19	27,1	28
21334-03-0350	350	353	26	-	-	256	288	36	-	-	19	27,1	30
21334-03-0400	400	402	26	192	224	320	352	22	128	160	19	27,1	30
21334-03-0450	450	452	26	224	256	384	416	8	160	192	19	27,1	28
21334-03-0500	500	501	26	256	288	416	448	26	160	192	19	27,1	25
21334-03-0550	550	550	26	256	288	480	512	12	224	256	19	27,1	22
21334-03-0600	600	599	26	288	320	512	544	30	224	256	19	27,1	20

必须利用所有安装位置，以达到最大负载值。

将导轨安装在抽屉中心线上或下方。

不适用于平装。

# 安装说明 21334-03

钢轨扣件

